
HOW TO MEASURE AN EXISTING DOORJAMB

To download printable ruler, visit www.kikgard.com.

Measure your doorjamb on the side where the lock strike plate is attached. The measurement should be from “reveal to reveal.” Be sure not to include the trim in your measurements.

Instructions for using the disposable ruler:

1. Place the ruler at eye level on the jamb wood.
2. Starting at the tip of the ruler where the arrows point, stretch the ruler from one edge of the jamb to the other edge – do not include the trim.
3. The colored line marked with the fraction closest to the measurement that “jumps out at you” should be the size of the jamb. That’s the size KIKGARD Shield you will need. (See page 7 for available sizes or contact us for sizes not listed.)

